



Wrist Pin Buttons & Clips

Order: 1-800-827-9210

Int'l: 1-321-636-9480

www.mtceng.com

sales@mtceng.com

Wrist Pin Buttons

All buttons and clips sold in pairs.

Kawasaki KZ900/1000/ GPZ1100 81-84

Diameter	Length (in)	Bore Size (SWP)	Bore Size (TSP)	Part Number
17mm	0.243	70mm	71mm	WPB-17-243
17mm	0.282	72mm	73mm	WPB-17-282
17mm	0.322	74mm	75mm	WPB-17-322
17mm	0.342	75mm	76mm	WPB-17-342
17mm	0.361	76mm	77mm	WPB-17-361
17mm	0.381	77mm	78mm	WPB-17-381
17mm	0.401	78mm	79mm	WPB-17-401
17mm	0.420	79mm	80mm	WPB-17-420
17mm	0.440	80mm	81mm	WPB-17-440
17mm	0.460	81mm	81mm	WPB-17-460
17mm	0.479	82mm	83mm	WPB-17-479
17mm	0.499	83mm	84mm	WPB-17-499
17mm	0.519	84mm	85mm	WPB-17-519
17mm	0.538	85mm	86mm	WPB-17-538

Suzuki GS1150 and GSXR

Diameter	Length (in)	Bore Size (SWP)	Bore Size (TSP)	Part Number
20mm	0.267	74mm	71mm	WPB-20-267
20mm	0.287	75mm	72mm	WPB-20-287
20mm	0.306	76mm	73mm	WPB-20-306
20mm	0.326	77mm	74mm	WPB-20-326
20mm	0.346	78mm	75mm	WPB-20-346
20mm	0.365	79mm	76mm	WPB-20-365
20mm	0.385	80mm	77mm	WPB-20-385
20mm	0.405	81mm	78mm	WPB-20-405
20mm	0.424	82mm	79mm	WPB-20-424
20mm	0.444	83mm	80mm	WPB-20-444
20mm	0.463	84mm	81mm	WPB-20-463
20mm	0.483	85mm	82mm	WPB-20-483
20mm	0.503	86mm	83mm	WPB-20-503
20mm	0.523	87mm	84mm	WPB-20-523
20mm	0.538	88mm	85mm	WPB-20-538
20mm	0.558	89mm	86mm	WPB-20-558

Suzuki GS1100

Diameter	Length (in)	Bore Size (SWP)	Bore Size (TSP)	Part Number
18mm	0.268	72mm	72mm	WPB-18-268
18mm	0.287	73mm	73mm	WPB-18-287
18mm	0.307	74mm	74mm	WPB-18-307
18mm	0.327	75mm	75mm	WPB-18-327
18mm	0.347	76mm	76mm	WPB-18-347
18mm	0.366	77mm	77mm	WPB-18-366
18mm	0.386	78mm	78mm	WPB-18-386
18mm	0.425	80mm	80mm	WPB-18-425
18mm	0.464	82mm	82mm	WPB-18-464
18mm	0.484	83mm	83mm	WPB-18-484
18mm	0.504	84mm	84mm	WPB-18-504
18mm	0.523	85mm	85mm	WPB-18-523

Cir-Clips

All clips sold in pairs

Install the end of one lock at 90 degrees from the pick lock groove. Use a stiff small bladed screwdriver and insert the tip into the pick lock groove while you wedge the lock into the groove without kinking or deforming the lock. After the first lock is in place, seat the lock by solidly hitting the wrist pin with a brass drift pin. Now install the connecting rod and the second lock. Seat the second lock in the same manner as the first. Just as a precaution, we recommend hitting each side of the wrist pin with the brass drift pin an additional time. Perform these functions on a cloth towel or soft rubber pad so no damage to the piston occurs.

Bore Size	Part Number
15mm	CIR-CC15
16mm	CIR-CC16
17mm	CIR-CC17
18mm	CIR-CC18
19mm	CIR-CC19
20mm	CIR-CC20
21mm	CIR-CC21
22mm	CIR-CC22
23mm	CIR-CC23
0.927in	CIR-CC927